



TAJNOTENT

INSTRUCTIONS FOR FITMENT



Front of cover

Back of cover
(Tail Gate)



Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

1) Check that contents are the same as above.

2) Unscrew two outside screws under window and attach front rail with cover attached and screw back using same screws just removed.

3) Attach plastic bracket onto side.



4) Remove first screw holding tie down hook at front. Replace with longest screw in kit.



5) Push bracket onto long screw as shown. Rest side brackets on top edge and using small black screws and nut attaché bracket to side rail.

6) Push small aluminium into black plastic piece protruding from rail fitted under window.

7) Using your foot push the aluminium rail so that the hole lines up with the hole where the long screw has been pushed through. Use nut to hold.

8) Unscrew the rest of the screws holding the hooks.



9) Push back rail into side rails, resting on tailgate. Use 2 screw pins to hold in place.



Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly. Only use a mild soap when cleaning your cover.

Thank you for your purchase, we hope it meets your requirements adequately.

Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668

WARRENTY: THE STITCHING IS GUARENTEED FOR 6 MONTHS. PLEASE ONLY USE SUNLIGHT DISH SOAP TO WASH THE COVER AND DUBBIN TO POLISH. ALL CAR WASH PRODUCTS AND POLISHES SHOULD NOT BE USED ON TONNEAU COVER, AS WELL AS HIGH PREASSURE HOSES AND BRUSHES.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston