



TAUNOTENT

INSTRUCTIONS FOR FITMENT



*This fitment applies to an Isuzu LWB
with and without roll bar LWB 2004 onwards*

*Part NO:
TT41*

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

TOOLS:

Electric Drill, 4.5mm steel drill bit, extension cord, pop-rivet gun, tape measure, pencil, all appropriate safety equipment, and all parts provided in the tonneau kit.

Note: After any holes are drilled apply rust inhibitor (provided) before any screws or rivets are fastened

1. Before commencing fitment, check the contents of the kit and ensure it is the correct cover for your bakkie by laying it over the load-body and ensuring it fits correctly.
2. Attach aluminium rail on the front edge of the load box under rear window with the open end facing towards the window using 4 self-taping drill screws, and slide cover into rail.
3. Pull cover towards back. You will see two strips sewn across the cover. The support braces go across the load box in the centre of these strips. Mark centre points and fit bow clips flush with top edge of load box using self-taping drill screws.
4. Insert longer support brace towards window and shorter towards tail gate.
5. Pull cover to back over tail gate. Turn up hem and mark centres of the back corners between loops, stitched on underside. Drill and pop rivet one bobbin on each corner.
6. At the front fit one saddle hook on either side as close to the front edge of the load box on to which the ends of the shock cord will be tied.
7. Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly.

Only use a mild soap when cleaning your cover.

Thank you for your purchase, we hope it meets your requirements adequately.

Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston